

### BEFORE YOU BEGIN

Fill your pool to the desired water level.

### INSTALLATION STEPS

- 1)** Select the appropriate ring size to fit comfortably over your skimmer box.  
Fix the ring to the lid with the screws provided. The remaining rings are not required and can be discarded.  
Set the arms on the unit so the valve is positioned at its highest point. Insert the unit into the skimmer box.  
Turn on the water supply and confirm water is flowing through the valve.
- 2)** Remove the centre cap and connect the garden hose to the valve fitting.  
Set the arms on the unit so the valve is positioned at its highest point. Insert the unit into the skimmer box.  
Turn on the water supply and confirm water is flowing through the valve.
- 3)** Take the unit out of the skimmer box and adjust the arms lower. Replace and inspect. Repeat as necessary.  
The Flip'n'Fill is set correctly when water stops flowing through the valve.
- 4)** Tighten the screws on the arms to hold the valve at the correct level.  
Your unit is now operational.



Screw the lid to the ring

